

25-I CLEANER CONCENTRATE

THE PREMIER ALL PURPOSE CLEANER FOR
ULTRASONIC CLEANING EQUIPMENT

This neutral pH compound is a highly effective combination of several powerful detergents, wetting agents, chelating agents, and emulsifiers. 25-I improves cavitation performance. It is a highly effective general purpose ultrasonic cleaning solution.

USE 25-I CLEANER CONCENTRATE ON:

- Aluminum
- Glass
- Plastics
- Ceramics
- Chromium
- Copper
- Zinc
- Magnesium
- Nickel
- Plastics
- Printed Circuit Boards
- Steel
- Iron

(Do not use on drill-rod/bearing steels.)

25-I CLEANER CONCENTRATE REMOVES:

- Grease
- Machining Chips
- Pickling Smuts
- Cutting Fluids
- Shop Soils
- Waxes
- Soldering Flux
- Oils
- Finishing Compounds
- General Contaminates

INSTRUCTIONS FOR USE:

- 1) Add 2 to 4 ounces of 25-I per 1 gallon of water.
- 2) For best results, solution should be heated to temperatures between 120°F to 180°F.

ORDERING INFORMATION:

Orders can be placed by calling Blue Wave at 800-373-0144, sending an email to sales@bluewaveinc.com, or by ordering online at www.bluewaveinc.com.

25-I CLEANER CONCENTRATE	PART NUMBER
Case (four 1-gallon containers)	100076-1
Drum (55 gallons)	100076-2



BLUE WAVE
ULTRASONICS



PROVEN SOLUTIONS. ENGINEERED EXCELLENCE.